


Valve(s) do not operate



**** Some controllers have electronic fuse and reset systems. If after the reset period, voltage is still not detected, the unit may be faulty**